

## INSTALLATION INSTRUCTIONS Control Box Relocation Cable Kit for SX10/12 Winches


APPLICATION:  
SX10/12 Winches  
PART NUMBER:  
90-42782

ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	1	MOTOR CABLE "A"	TORQUE WRENCH
2	1	MOTOR CABLE "B"	13MM SOCKET
3	1	MOTOR CABLE "C"	ALLEN WRENCH
4	1	DRUM LIGHT CABLE	RATCHET
5	1	CONTROL BOX GROUND CABLE	
6	1	POWER CABLE	

**ANTI-SEIZE LUBRICANT MUST BE USED ON ALL STAINLESS STEEL FASTENERS TO PREVENT THREAD DAMAGE AND GALLING**

### PROCEDURE

1. Remove contents from box, verify if all parts listed are present and free from damage. Carefully read and understand all instructions before attempting installation.  
**Failure to identify damage before installation could lead to a rejection of any claim.**
2. Disconnect the original cables from the from the winch motor.
3. Install (1) yellow terminal boot onto each end of the 6 foot long Motor Cable "A".
4. Install (1) red terminal boot onto each end of the 6 foot long Motor Cable "B".
5. Install (1) black terminal boot onto each end of the 6 foot long Motor Cable "C".
6. Install Motor Cable "A" with the yellow terminal boot onto the yellow motor terminal. See **Figure 1**.
7. Install Motor Cable "B" with the red terminal boot onto the red motor terminal. See **Figure 1**.
8. Install Motor Cable "C" with the black terminal boot onto the black motor terminal. See **Figure 1**.
9. Install the black ground cable included with the SX winch onto the motor ground terminal. See **Figure 1**.
10. If the 6 foot long control box ground cable (**item 5**) is needed, connect one end of the 6 foot long control box ground cable to the motor ground terminal. See **Figure 1**.



11. Remove the control box from the winch.
12. Disconnect the drum light cable. See **Figure 2**.
13. Attach the 6 foot long drum light cable (**item 4**) to the drum light cable on the winch.
14. Route the motor cables, drum light cable, and 6 foot long control box ground cables towards the location of the control box.
15. Remove the control box lid.
16. Install the motor cables and 8 foot long power cable onto the contactor according to **Figure 3**. Tighten the M8 hardware to 15-18 ft-lbs.




Figure 2




Figure 3

17. If the 6 foot long control box ground cable (**item 5**) is needed, connect the end of the 6 foot long control box ground cable and the short control box ground cable to the contactor mounting bolt indicated in **Figure 4**. Alternatively, the short control box ground cable can be installed onto the vehicle frame. See **Figure 5**.
18. Attach the 6 foot long drum light cable to the control box drum light cable.
19. Reinstall the control box lid.
20. Mount the control box.
21. Route the black ground cable and 8 foot long power cable towards the vehicle battery.
22. Connect the black ground cable to the battery ground terminal.
23. Connect the 8 foot long power cable to the battery positive terminal.




Figure 4



Figure 5

Thank you for choosing Westin products  
for additional installation assistance please call  
Customer Service (800) 793-7846  
[www.westinautomotive.com](http://www.westinautomotive.com)



## WARNING



Failure to follow these instructions could lead to death, personal injury, and / or property damage.

Failure to follow these instructions could lead to death, personal injury, and / or property damage.

### FASTENERS:

All Westin supplied fasteners must be utilized and installed in accordance with the installation instructions and apply torque to the specifications as defined. **DOUBLE CHECK ALL FASTENERS BEFORE INITIAL USE, AND PERIODICALLY IN THE FUTURE TO ENSURE PROPER FUNCTION AND SAFETY.**

### DRILLING:

Most Westin products do not require drilling for installation. If drilling is defined as required, use caution when drilling a vehicle. **FAILURE TO REVIEW AN AREA TO BE DRILLED MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.**

### EYE PROTECTION:

**ALWAYS WEAR SAFETY GLASSES OR GOGGLES DURING THE INSTALLATION PROCESS TO AVOID PERSONAL INJURY.**

### MAXIMUM TOWING/CARRYING CAPACITY: (if applicable)

The Westin Receiver Hitches will have a visible tow rating label affixed directly on the product. User should never exceed the vehicle manufacturers maximum tow and weight rating regardless of the capacity of the hitch. **FAILURE TO FOLLOW THESE GUIDELINES WILL VOID THE WESTIN WARRANTY AND MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.**

### FOR CALIFORNIA RESIDENTS ONLY-PROP 65 WARNING:

Some products may contain chemicals such as DEHP, which can cause cancer, birth defects or other reproductive harm. For more info go to [www.p65warnings.ca.gov](http://www.p65warnings.ca.gov)



Westin Automotive Products, Inc.  
320 W. Covina Blvd  
San Dimas, Ca. 91773

Thank you for choosing Westin products  
for additional installation assistance please call  
Customer Service (800) 793-7846  
[www.westinautomotive.com](http://www.westinautomotive.com)