

## SX SERIES SERVICE PARTS

|   |   | SX10        | SX10SR   | SX12     | SX12SR   |
|---|---|-------------|----------|----------|----------|
| CONTENTS  | DESCRIPTION                             | PART NUMBER |          |          |          |
| 3, 4, 5, 6, 7, 8,<br>9, 10, 11, 12,<br>14, 43, 44 | Control Box Assembly                    | 90-42642    | 90-42642 | 90-42642 | 90-42642 |
| 6   | Contactora                              | 90-32492    | 90-32492 | 90-32492 | 90-32492 |
| 34, 35, 36, 37,<br>38, 39, 40, 41                 | Clutch Assembly                         | 90-42657    | 90-42657 | 90-42657 | 90-42657 |
| 22, 45, 46  | Motor Assembly                          | 90-42648    | 90-42648 | 90-42651 | 90-42651 |
| 7, 10   | Remote Control Socket                   | 90-42645    | 90-42645 | 90-42645 | 90-42645 |
| 9, 25, 26, 27,<br>30, 45, 46, 47,<br>48           | Small Parts Kit                         | 90-42660    | 90-42660 | 90-42660 | 90-42660 |
| 1   | Tie Bar & Drum Light                    | 90-41443    | 90-41443 | 90-41443 | 90-41443 |
| N/A   | Fairlead, Hawse<br>(Not Shown)          | N/A         | 90-41446 | N/A      | 90-41446 |
| N/A   | Fairlead, Roller<br>(Not Shown)         | 90-32493    | N/A      | 90-32493 | N/A      |
| N/A   | Hook (Not Shown)                        | 90-42666    | 90-42666 | 90-42666 | 90-42666 |
| N/A   | Power Cable Kit<br>(Not Shown)          | 90-42669    | 90-42669 | 90-42669 | 90-42669 |
| N/A   | Remote Control, Wired<br>(Not Shown)    | 90-42654    | 90-42654 | 90-42654 | 90-42654 |
| N/A   | Remote, Wireless<br>Control (Not Shown) | 2277R       | 2277R    | 2277R    | 2277R    |
| N/A   | Rope, Steel Cable Wire<br>(Not Shown)   | 90-24576    | N/A      | 90-24576 | N/A      |
| N/A   | Rope, Synthetic<br>(Not Shown)          | N/A         | 90-24595 | N/A      | 90-24595 |

| ITEM NO. | PART NUMBER  | DESCRIPTION  | QTY. |
|----------|--|--|------|
| 1        | 1710200-12-1   | TIE BAR  | 1    |
| 2        | 1710200-13   | DRUM, SX   | 1    |
| 3        | 1710200-15-1   | LID, CONTROL BOX, SX   | 1    |
| 4        | 1710200-15-2   | DUST COVER, SX   | 1    |
| 5        | 1710200-15-3   | CONTROL BOX BASE, SX   | 1    |
| 6        | 1710200-15-4   | CONTACTOR, 12VDC   | 1    |
| 7        | 1710200-15-5   | SOCKET, REMOTE CONTROL   | 1    |
| 8        | 1710200-15-6   | PIN - DUST COVER   | 1    |
| 9        | 1710200-15-8   | SOCKET SEAL  | 1    |
| 10       | 1710200-15-12  | SCREW, FLAT HEAD M3  | 2    |
| 11       | 1710200-15-11  | SCREW, SOCKET HD M4  | 4    |
| 12       | 1710200-15-10  | SCREW BUTTON HD M4-0.7*8MM   | 1    |
| 13       | 1710201-15-16 (SX10SR/SX12SR)                            | WIRELESS RECEIVER SX   | 1    |
| 14       | 1710200-15-17  | INSERT, CONTROL BOX  | 1    |
| 15       | 1710200-16   | SCREW, SOCKET, M8  | 4    |
| 16       | 4-51-0823  | M8 SPRING WASwHER  | 4    |
| 17       | 1710200-20   | BADGE SX LOGO  | 1    |
| 18       | 1710200-21 (SX10/SX10SR)<br>1712200-20 (SX12/SX12SR)     | BADGE SX-10 (SX10/SX10SR)<br>BADGE SX-12 (SX12/SX12SR)               | 1    |
| 19       | 1710200-22   | DRIVE SHAFT  | 1    |
| 20       | 1710200-11-3   | DRUM SUPPORT - MOTOR END   | 1    |
| 21       | 1710200-11-1   | MOTOR HOUSING  | 1    |
| 22       | 1710200-11-2 (SX10/SX10SR)<br>1712200-1-12 (SX12/SX12SR) | MOTOR, 12V, 5.5 HP (SX10/SX10SR)<br>MOTOR, 12V, 6.0 HP (SX12/SX12SR) | 1    |
| 23       | 1710200-11-4   | SCREW, BUTTON HEAD, M5-0.8 X 20MM                                    | 4    |
| 24       | 1710200-11-5   | WASHER-M5 SPRING   | 4    |
| 25       | 1710200-11-9   | GASKET, DRUM SUP-DRUM  | 2    |
| 26       | 1710200-11-10  | DRUM-BEARING   | 2    |
| 27       | 1710200-11-8   | BRAKE  | 1    |
| 28       | 1710200-14-2   | DRUM SUPPORT, GEAR BOX END   | 1    |
| 29       | 1710200-14-1   | GEAR BOX SX  | 1    |
| 30       | 1710200-14-7   | GASKET, GEARBOX-DRUM SUPPORT   | 1    |
| 31       | 1710200-14-4   | GEAR TRAIN, SX   | 1    |
| 32       | 1710200-14-10  | WASHER, SPRING M6  | 8    |
| 33       | 1710200-14-3   | SCREW, SOCKET HEAD M6  | 8    |
| 34       | 1710200-14-11  | SET SCREW, M6  | 1    |
| 35       | 1710200-14-5-1   | CLUTCH BASE  | 1    |
| 36       | 1710200-14-5-2   | O-RING, 23MM I.D.  | 1    |
| 37       | 1710200-14-5-3   | CLUTCH PIN   | 1    |
| 38       | 1710200-14-5-4   | O-RING, 11MM I.D.  | 1    |
| 39       | 1710200-14-5-5   | SPRING, CLUTCH   | 1    |
| 40       | 1710200-14-5-6   | CLUTCH HANDLE SX   | 1    |
| 41       | 1710200-14-5-7   | SCREW, CAP HEAD M4   | 1    |
| 42       | S102731  | SET SCREW M8 X 1.25 - 10mm LONG                                      | 1    |
| 43       | 1710200-15-18  | SCREW - PHILLIPS HEAD M6-1.0*8mm                                     | 2    |
| 44       | 1710200-17-2   | SCREW - BUTTON HEAD M5-0.8 X 25mm                                    | 4    |
| 45       | 1710200-11-7   | GASKET, MOTOR-DRUM SUPPORT   | 2    |
| 46       | 90-42660-3   | O-RING, MOTOR BOLT   | 2    |
| 47       | 1710200-14-6   | BALL BEARING, GEARBOX  | 1    |
| 48       | 90-42660-1   | BUSHING, GEARBOX SX  | 1    |

